

## **Adjustment Program (Version 1.0) for Stylus Photo 2000P Operating Instructions**

Compared with MS-DOS program, the User Interface of this Windows program has quite changed. But the procedure of adjustment is the same as MS-DOS program.

### **1. Operating Environment:**

- Windows 95 OSR2.0 or higher and Windows98.
- Before start the program, please make sure LPT1 is used as the printer port and the printer is connected with a parallel cable.(for Windows 95 or Windows 98) Note you use any of EPUSB1 - EPUSB3 when confirming the USB port function.(This function is only available on Windows 98.)

### **2. Setup procedures:**

The following procedures are required to execute this program.  
Insert Adjustment Program Disk1 and boot Setup.exe.  
Follow the procedures, insert Disk2 and complete installing the Adjustment Program.  
This enables you to perform the Adjustment Program from the "Start Menu".  
Correct program is automatically installed according to your OS; Windows 95 or Windows 98.

### **3. Cautions:**

- 1) Please make any adjustments or settings using a parallel cable.
- 2) When you confirm the function of USB port properly, you must use Windows98 pre-installed PC. It cannot function properly on Windows95.
- 3) When you operate this program on the Windows 95 or Windows 98, you cannot operate it with Status Monitor is running. Close Status Monitor on Task tray before start the adjustment program.
- 4) Do not change the setting for "Font size" in "settings tab" of the "Display Property" window.
- 5) Please do not start the Service Program before connecting the printer with a parallel I/F cable.  
If you do not follow the instruction, the program will freeze.
- 6) Please do not send any commands during Check Pattern printing.
- 7) In case the power's turned off, or the parallel I/F cable or USB I/F cable is removed during the Adjustment Program, please restart the Adjustment Program.